

# SE

## User Manual



## **WARNING**

Electromagnetic Interference (“EMI”) can cause powered vehicles to behave erratically, which could be dangerous to the user. For your safety and protection, it is **IMPERATIVE** that you take time to read Chapter 6 (“EMI WARNING”) before operating the SE.

## **WARNING**

Read the User’s Manual carefully before operating the  
SE

If you do not fully understand any part of this Manual, please contact your dealer or any of our Service Centers - as injury or Damage may occur from misuse!

Serial Number and Manufacturer’s data are fixed to the back side of the Headlight Housing (subject to change as per local ordinances).

P/N PR00056

Date: April 2015

Edition: 01

Revision : 08

Products: SE - Single Seat  
SE – XXL Seat (65 cm)  
SE – Wide Seat (79 cm)

## **CE CERTIFICATION**

The Afikim Electric Vehicles Ref. Registration Number with the Competent Authority (UK) is:

**CA 000292.**

Our Authorized Representative with the Competent Authorities is:

MEDES LTD.  
POB 231  
Stanmore, Middlesex, HA7 4YA, England

TEL/FAX: 0044-1-954-9964

## **CONTENTS**

SAFETY INSTRUCTIONS.....	6
CHAPTER 1 - GENERAL DESCRIPTION OF THE SE.....	7
CHAPTER 2 - ADJUSTMENT & OPERATING INSTRUCTIONS.....	10
CHAPTER 3 - MAINTENANCE.....	12
CHAPTER 4 - CHARGING.....	15
CHAPTER 5 - TROUBLESHOOTING AND FAULT REPAIR.....	20
CHAPTER 6 - EMI WARNING.....	22

## **CHAPTER 1 - OVERVIEW OF THE SE**

Main features:

Congratulations on choosing the SE as your electrically powered vehicle.

The SE is easy to operate. The relatively large wheels enable driving on unpaved roads, over rough terrain and to overcome obstacles as high as 4" (10 cm). The SE can climb slopes up to 21% - Single, 18% - Double. The braking system stops the SE smoothly and a short distance after the Operating Lever is released.

A standard hand brake is also provided for backup. The Seat is spacious, comfortable and can be rotated for easy access (standard Seats). All controls are conveniently located and are simple to operate. Under normal conditions the SE can travel approximately 40 km (25 miles) before the batteries require recharge.

The SE is developed to use dry or gel batteries only.

The SE Series includes -

Model SE -     - Single Seat  
                  - XXL Seat (65 cm)  
                  - Wide Seat (79 cm)

Please see Figure No. 1 for detailed specifications .

## **SAFETY INSTRUCTIONS**

1. Please note and strictly adhere to the following Safety Instructions. Additional Warnings and Notices are printed in this User's Manual; it is imperative that you read carefully all chapters of this Manual before operating the SE. It is also advisable to refresh your memory by re-reading this Manual periodically. Use gel/dry batteries only.
2. Get acquainted with the SE and its operational features before driving it.
3. Drive slowly (Place Speed Selector in position 1) until you get used to the SE, to its various functions, safety features, and to its braking capabilities and limitations.
4. Watch carefully for pedestrians and drive your SE accordingly. In crowded areas always drive with the Speed Selector at Low Speed (position 1).
5. Drive **only where permitted** according to all applicable local laws and local ordinances.
6. **Never remove any of the SE safety** parts like Antitip Device, Fenders, or Emergency Brake lever
7. **DO NOT** turn the Main Key Switch to "OFF" position while in motion; this may cause abrupt and excessive deceleration which in turn may cause injury to the user and damage to the SE.
8. Do not release the Manual Release Lever of the Electromagnetic Brake when the SE is on a slope.
9. The load in the Rear Basket should not exceed 20 kg (44 lbs).
10. The SE is designed and built to carry ONE person only on the Single Seat model.  
**Never** operate it with an additional person on board, not even a child. Ask your dealer about carrying two persons on the Double Seat model.
11. Do not change the Speed Selector position while driving.
12. **NEVER** use the SE for climbing up or riding down stairs.
13. If for any reason the SE does not stop when you release the Operating Lever , immediately use the Hand Brake to stop the SE and turn the Main Key Switch to "OFF". **Contact your dealer immediately.**
14. **NEVER** use a hose for cleaning. This may severely damage the power and electronic components. Use only a damp cloth and mild detergent.

### **WARNING !!!**

**Special care must be taken to prevent children from operating the SE.**

## **GENERAL DESCRIPTION OF THE SE**

**Note:** The numbers in parentheses refer to the parts illustrated on Figure 1.

Handlebars (2)	<p>There are two separate and independently adjustable handlebars, one of which houses the controls for the SE. Your SE is delivered to you with right-hand controls. (Left-hands controls can be ordered through your dealer).</p> <p><b>NOTE :</b> On the Double Seat model the left handlebar is shorter to allow for easier steering by the driver with 2 people on board. For a single user two handlebars of the same length can be supplied. Ask your dealer.</p>
Headlight (3)	
Charging Socket (4)	The socket is used to connect the charger plug for batteries charging.
Seat (6)	<p>The Single SE Seat is equipped with folding armrests (1) to allow convenient access to the Seat. The Seat itself can be rotated. The upholstery may be removed for cleaning. (A deluxe orthopedic adjustable Seat is also available. Ask your dealer).</p> <p>The Double SE Seat is equipped with folding armrests (1) as in the Single Seat model and can be tilted to make service more accessible.</p> <p>It can also be supplied with a Canopy (10) for protection from sun and light rain.</p>
Fuses (5)	<p>5A - Main Fuses 2x40A or 70/80A– Semi Automatic</p> <p>5B - Light Fuse (3A) - Semi Automatic</p> <p>5C - Charging Fuse 15A – Semi Automatic</p>
Seat Rotation Lever (7)	The Lever is used to swivel the Seat 45 degrees in either direction, to ease the driver's access to the Seat.
Rear Basket (8) (Optional for Single Seat model and standard for Double Seat model)	For carrying parcels and personal effects. Maximum load 20 kg (44 lbs).
Serial No.	Serial Number and Manufacturer's data are located on the rear side of the main lamp, and of the back of rear tray.
Manual Release Lever of Electromagnetic Brake (11)	<p>Located under the seat at the rear right of the SE, the Electromagnetic Brake Manual Release Lever allows free movement of the SE. To release, simply pull the brake lever as shown in the rear label. To engage the brake, push lever opposite.</p> <p>When lever is released the vehicle can not be operated.</p>





Figure 1





## TECHNICAL SPECIFICATIONS

MODEL No. :		SE		SE		SE	
		Single Seat		XXL Seat (65 cm)		Wide Seat (79 cm)	
Units		Metric	USA	Metric	USA	Metric	USA
<b>Dimensions*</b>	Length (without rear basket) (with rear basket)	150 cm 175 cm	59" 69"	170 cm	67"	170 cm	67"
	Width	72 cm	28"	76 cm	30"	90 cm	35"
	Height (for transport: handles, seat and front wheel removed)	77 cm	30.5"	77 cm	30.5"	77 cm	30.5"
	Ground clearance	12 cm	5"	12 cm	5"	12 cm	5"
<b>Weights *</b>	Total, without batteries	75 kg	165 lbs	90 kg	198 lbs	90 kg	198 lbs
	Total, with batteries	115-125 kg	254-276 lbs	130-140 kg	287-309 lbs	130-140 kg	287-309 lbs
	Maximum load (including rear basket load)	200 kg	440 lbs	200 kg	440 lbs	200 kg	440 lbs
<b>Speed **</b>	Forward (Speed selector position No. 2)	10 km/h	6.2 mp/h	10 km/h	6.2 mp/h	10 km/h	6.2 mp/h
	Forward (Speed selector position No. 1)	6 km/h	3.7 mp/h	6 km/h	3.7 mp/h	6 km/h	3.7 mp/h
	Reverse	6 km/h	3.7 mp/h	6 km/h	3.7 mp/h	6 km/h	3.7 mp/h
<b>Climbing ability</b>	Maximum slope (100 kg- 220 lbs load)	21%		18%		18%	
	Obstacles	12 cm	5"	12 cm	5"	12 cm	5"
<b>Tires (pneumatic)</b>	Front tire size		10x27.5"		10x27.5"		10x27.5"
	Rear tires size		14x2.75"		14x2.75"		14x2.75"
	Pressure		27-33 psi		27-33 psi		27-33 psi
<b>Batteries ***</b>	Gel/dry batteries only	60-70 Ah	2x12 V	60-70 Ah	2x12 V	60-70 Ah	2x12 V
<b>Travel distance</b>	Fully charged batteries, level surface, driver 75 kg ( 165 lbs)	40-45 km	25.0 miles	40-45 km	25.0 miles	40-45 km	25.0 miles

All technical specifications are subject to change without prior notice.

All dimensions are in round figures.


\* Dimensions and weight do not include SE Canopy.

\*\* Subject to Local ordinance, the maximum speed can be changed by the manufacturer (i.e. 12km/h-7.5 mp/h or 15 km/h - 9.3 mp/h).

\*\*\* Deep cycle batteries. Consult your dealer for other sizes.

## **CHAPTER 2 - ADJUSTMENT & OPERATING INSTRUCTIONS**

**(Reference numbers refer to the figures at the bottom of each page)**

<p>Adjusting the Handlebars</p>	<p>Adjust angles and height of both handlebars as follows:</p> <ul style="list-style-type: none"><li>• Release the Handlebars secure screws (1), which secures the handlebars in place.</li><li>• Adjust the height and angle of your handlebars, by turning, while raising or lowering the handlebars.</li><li>• Tighten handlebars at the desired height and direction: secure the Handlebars secure screws (1) .</li></ul>
<p>Adjusting the Hand Brake</p>	<p>The hand brake cable mechanism can be adjusted by any authorized serviceman, dealer or by any professional authorized to adjust hand brakes mounted on bicycles or motorcycles.</p> <p><b>The Hand Brake is part of your safety system. DO NOT adjust the Hand Brake by yourself - get professional assistance!</b></p> <p><b>Note</b> : handbrake may be also assembled on the right handlebar.</p>
<p>Seating into the SE</p>	<p>Before driving the SE make sure that the Charging Plug is disconnected from the Charging Socket (3).</p> <p><b>Note: While the Charging Plug is inserted in the Charging Socket, the unit cannot be operated.</b></p> <p>Lift the Lever (4) upward, rotate the Seat (5) and raise the Armrest (2) to give you easy access to the Seat.</p>
	


## Key Switch

- The SE has a Main Key Switch (9) - located on the right side of the Headlight Housing.


The Main Key Switch has two positions:

- **“OFF”** - The SE cannot be driven and the Electromagnetic Brake is locked.
- **“ON”** - Power is supplied to the SE. The Electromagnetic Brake releases automatically when the Operating Lever is squeezed.




To operate the SE, insert the key into the Main Key Switch and turn it to “ON” (clockwise). The switch will remain in this position and the green (2) light will be lit.




Automatic Shut Off	When Key Switch is at "ON" position, after a few minutes (about 20 minutes) without using the Operating Lever, the control system will be shut off automatically to save battery energy. In such cases, to restart control system, turn Main Key Switch "OFF" and "ON" again.
Battery Status Indicator	The <b>Battery Status Indicator</b> (1) located on top of the Headlight Housing shows you the remaining capacity of the batteries. When the indicator shows that mid-half capacity remains, recharge batteries as soon as possible. When the indicator points that to first or second segment on the left there are only about 5 km (3 miles) to go.
Fault Indicator	When the green light of the Fault indicator (2) is lit, the vehicle is "ready". When the Fault Indicator (2) is Green/Red Flashing the Vehicle is in Fault condition or the brake manual lever is released. (The Flashing Code can be Decoded by technician).
Forward/Reverse Selector	The Forward/Reverse Selector (14) is located on the handlebar. Select the desired direction (as marked). In reverse mode, a warning buzzer sounds automatically (in certain models only and subject to local ordinances). <b>Warning: Do not change Selector position while the SE is in motion.</b>



<p>Speed Range Selector</p>	<p>The Speed Range Selector (16) is located on the left side of the Headlight Housing. It has two positions:</p> <ul style="list-style-type: none"> <li>• Mark “1” (lower position): Low speed - up to 6 km/h (3.1 mph).</li> <li>• Mark “2” (upper position): High speed - 10 km/h (6.2 mph).</li> </ul> <p>Do not shift the selector while the SE is in motion.</p> <p><b>Note: When driving the SE inside a building or in a crowded area, use only position 1 (Low speed).</b></p>
<p>Operating Lever (red) and Manual Hand Brake</p>	<p>To start driving, squeeze the <b>Operating Lever (18)</b> gently until you reach the desired speed.</p> <p><b>The speed is directly proportional to the deflection of this Lever .</b></p> <p>To stop - release the <b>Operating Lever (18)</b>. The SE will stop gradually.</p> <p><b>Additionally, emergency braking is possible using the Manual Hand Brake (17).</b></p> <p><b>Note:</b> Hand Brake is usually assembled on the Left Handle Bar but sometime it is assembled on the Right side.</p>
<p>Signaling</p>	<p>Before turning, shift the “Turn Signal Switch” (19), on the Handlebar to the desired direction - left for left, right for right. This will activate blinking lights on the rear fenders. A warning buzzer also sounds (in certain models only and subject to local ordinances).</p>



Horn/Buzzer (in certain models only)	<p><b>Push Button (20)</b> activates a buzzer. The buzzer sounds <b>automatically</b> under the following conditions (<i>subject to change where prohibited by law</i>):</p> <ol style="list-style-type: none"> <li>1. When reversing.</li> <li>2. When operating the "Turn Signal Switch" (Right or Left).</li> <li>3. When the "Emergency Electromagnetic Brake Lever " is operated.</li> </ol>
Headlight Switch	Turn on the Headlight (24) with Light Switch (23). This switch activates both the Headlight and the Rear Lights (28).
Hazard Warning	The Hazard Button (20) operates all flashing lights on the SE. Pushing the button once turns the lights ON. A second push turns them OFF.



Parking	<p>After stopping, turn the Main Key Switch to OFF and remove the key. The lights will turn OFF. The Electromagnetic Brake is engaged (locked).</p> <p><b>Notes: The Electromagnetic Brake is automatically locked whenever the Operating Lever is released and after the SE stops completely.</b></p>
---------	--


## CHAPTER 3 - MAINTENANCE

**Note:** The numbers in parentheses refer to the parts illustrated in figure 2.


Although the SE requires minimal maintenance, do not neglect it. When servicing the SE, make sure that it stands on a level surface and that the key is not inserted. In addition, lock the Hand Brake.

Periodic Maintenance Check	No	Type of Service	Frequency
	1	Check water level in the batteries. Add water as needed. <b>(Lead acid batteries only)</b>	Bimonthly or as per manufacturer's instructions
	2	Check air pressure in all tires.	Every two weeks
<b>Note: To check the batteries, the Batteries Cover located under the Seat must be removed.</b>			
Removing the Batteries Cover (33) (Single Seat Model)	Remove the Seat (29): hold the backrest at marked position with one hand and press Lever (30) with the other, lifting the seat up off its pivot Release Batteries Cover 4 securing screws (31). Lift the Batteries Cover until it is released from the Seat Pivot (32).		
Replacing the Batteries Cover (33) (Single Seat Model)	The replacement of the Batteries Cover is done in reverse order; MAKE SURE that the Batteries Cover (33) fits onto it's place. Secure with 4 screws (31).		





**Single Seat Model**



**Double Seat Model**

**Figure 2. Removing the Gray Cover for Maintenance**

<p>Removing the Batteries Cover (33) (Double Seat Model)</p>	<p>Release the lock lever (37) under the Seat and tilt Seat (36) back about 70 degrees until it is almost standing on the rear part of the frame. Remove the Batteries Cover (33) as described above (for Single Seat Model).</p>
<p>Replacing the Batteries Cover (33) (Double Seat Model)</p>	<p>Replacement of the Batteries Cover is done in reverse order. Tilt Seat back and mount on Seat Shaft.</p>
<p>Batteries</p>	<p>Every two months, check the water level in both batteries.</p> <p><b>Note: Failure to maintain water level in the batteries will cause damage and void the manufacturer's warranty.</b></p>
<p>Checking Water Level</p>	<p>Remove the Batteries Cover. Open the strap holding the batteries in place and check the water level in each of the battery cells. Normal water level is approximately 6 mm (1/4") above the plates. If the water level is lower, add distilled water.</p> <p><b>Note: use ONLY distilled water.</b></p>
<p>Tires</p>	<p>Correct air pressure in the tires is essential for optimal steering and stability of the SE. Check air pressure every two weeks. Inflate to the proper air pressure (27-33 psi).</p> <p>Solid tires (optional) should be checked visually and replaced if excessive wear or damage is noticed.</p>

## **CHAPTER 4 - CHARGING**

Read Charger's manual before using the charger.

**Warning: If you use a different charger, ask your dealer for instructions.**

### **CHARGING BATTERIES**

(See figure 3)

1. Insert the Charging Plug (2) into the Charging Socket (3) located on the Panel at the front of the Batteries Cover, at the center.


Make sure the plug is fully inserted into the socket.

2. Plug the power cord of the charger into a wall outlet.
3. When charging is completed and you are ready to go - unplug the charger from the wall outlet and remove the charger plug from the SE.
4. In ideal storage conditions, batteries which were charged to full capacity and were not used should be recharged every 6 months.
5. If you are planning not to use your SE for an extended period of time, we recommend charging it for two days and then disconnecting the batteries.
6. If you have not used your SE for an extended period of time, charge the batteries for at least 24 hours before driving.

### Recommended reCharging routine

1. Use the scooter along the day as needed or until charging is low , according to the battery indicator.
2. At the end of the day, recharge the scooter batteries along the night.
3. No need to disconnect the batteries at the end of the charging. The charger is Automatic and stops itself.
4. No need to recharge the scooter batteries at the end of every drive, unless you are not intending to use the scooter any more on that day.
5. In case of recharge the scooter along the day, you should make a full charging.
6. It is not recommended to leave the batteries uncharged for a few days as it can reduce the travel distance and battery's life.

- **Note: There is NO need to disconnect the Charging Plug promptly after the charging is complete.**



**Figure 3. Charging batteries**

## **CHAPTER 5 - TROUBLESHOOTING AND FAULT REPAIR**

The following table provides troubleshooting and repair instructions for symptoms encountered when operating the SE. It presents the best ways to handle the faults. The table contains three columns:

**The Symptom** - describes the functional problem that results from the fault.

**Probable Cause** - lists all probable causes for the relevant symptom. The probable causes are listed logically by order of probability: the first one is the most probable.

**Remedy** - lists the action to be taken to solve the problem. The appropriate remedy appears opposite each probable cause. These remedies should solve the problem; if not, continue down the list to the next cause/remedy.

Remember: you may contact your dealer at any time for further professional support.

<b>No.</b>	<b>Symptom</b>	<b>Probable Causes</b>	<b>Remedy</b>
1	Flat tire and unstable driving.	<ul style="list-style-type: none"> <li>• Low air pressure.</li> <li>• Puncture.</li> </ul>	<ul style="list-style-type: none"> <li>• Pump to normal pressure.</li> <li>• Repair the punctured tire.</li> </ul>
2	The Service LED Flashed and the vehicle does not move.	<ul style="list-style-type: none"> <li>• Manual Release Lever pushed forward.</li> <li>• Controller Coded Fault.</li> </ul>	<ul style="list-style-type: none"> <li>• Pull Lever Backwards.</li> <li>• Ask for technical assistance.</li> </ul>
3	The Service LED Flashed and the vehicle moves only at low speed.	<ul style="list-style-type: none"> <li>• Electric column is at up.</li> </ul>	<ul style="list-style-type: none"> <li>• Lower column position.</li> </ul>
4	Manual Mechanical Brake Lever is fully pressed but the vehicle does not stop.	<ul style="list-style-type: none"> <li>• Loose hand brake mechanism.</li> </ul>	<ul style="list-style-type: none"> <li>• Brake Cable needs to be tightened. Ask your technician to tight the Brake Cable.</li> </ul>
5	The Key Switch is turned to "ON" (clockwise), but the "ON" light does not come on.	<ul style="list-style-type: none"> <li>• Main fuse popped out.</li> </ul>	<ul style="list-style-type: none"> <li>• Reset fuse.</li> </ul> <p><b>Note:</b> Do not reset fuse more than twice. If the symptom recurs after resetting the second time, call the authorized dealer for further technical support.</p>

## **TROUBLESHOOTING AND FAULT REPAIR (Cont.)**

<b>No.</b>	<b>Symptom</b>	<b>Probable Causes</b>	<b>Remedy</b>
6	SE does not move when squeezing the Operating Lever .	<ul style="list-style-type: none"> <li>• Main Key Switch is in OFF position.</li> <li>• Charging Plug is installed in Charging Socket.</li> <li>• The Mechanical Release Lever of the Electromagnetic Brake is pushed Forward.</li> <li>• Control system failure</li> </ul>	<ul style="list-style-type: none"> <li>• Turn the key to “ON” position.</li> <li>• Disconnect the Charging Plug from the SE.</li> <li>• Pull out the Lever Backward</li>   <li>• Call for technical support.</li> </ul>
7	Intermittent drive.	<ul style="list-style-type: none"> <li>• Battery capacity low.</li>   <li>• Failed connections</li>   <li>• Faulty battery.</li> </ul>	<ul style="list-style-type: none"> <li>• Charge batteries for at least 18 hours.</li> <li>• Remove Gray Cover and check the battery cables connection. In case of corrosion of the terminals, clean the terminals with a damp clean cloth.</li> <li>• If, after recharge, the red lamps are still ON, the battery may be faulty. For replacement, contact your dealer.</li> </ul>
8	RIGHT or LEFT turn signal light is inoperative.	<ul style="list-style-type: none"> <li>• Blown light fuse or popped out - Figure 1.</li>   <li>• Burnt out bulb.</li> </ul>	<ul style="list-style-type: none"> <li>• Replace light fuse or reset fuse if automatic - see Figure 1.</li> <li>• Replace bulb.</li> </ul>
9	Headlight and/or rear light are not lit.	<ul style="list-style-type: none"> <li>• Blown light fuse or popped out - Figure 1.</li>   <li>• Burnt out bulb.</li> </ul>	<ul style="list-style-type: none"> <li>• Replace light fuse or reset fuse if automatic - see Figure 1.</li> <li>• Replace Headlight bulb.</li> </ul>

## **CHAPTER 6 - EMI WARNING**

All types of electrically powered vehicles, such as powered wheelchairs and motorized scooters (**in this text all types will be referred to as “powered vehicles”**) may be susceptible to electromagnetic interference (EMI). This is interfering **electromagnetic energy (EM)** emitted from sources such as radio and TV stations, amateur radio (HAM) transmitters, two-way radios and cellular phones. The interference (from radio wave sources) can cause the powered vehicle to release its brakes, move by itself, or move in unintended direction. It can also damage the powered vehicle's control system. The intensity of the interfering EM energy can be measured in volts per meter (V/m). Each powered vehicle can resist EMI up to a certain intensity. This is called its “immunity level”. The higher the immunity level, the greater the protection. At this time, current technology is capable of achieving immunity level, which would provide useful protection from the more common sources of radiated EMI. This vehicle as shipped, with no further modification, has an immunity level of 10 V/m.

There are a number of sources of relatively intense electromagnetic fields in everyday environment. Some of these sources are obvious and easy to avoid. Others are not apparent and exposure is unavoidable. However, we believe that by following the warning listed below, your risk of EMI will be minimized.

The sources of radiated EMI can be broadly classified into three types:

1) **Hand-held portable transceivers** (transmitters-receivers) with the antenna mounted directly on the transmitting unit. Examples include: citizen band (CB) radios, “walkie talkies”, security, fire and police transceivers, cellular telephones and other personal communication devices. NOTE: some cellular telephones and similar devices transmit signals while they are ON, even when not being used.

2) **Medium-range mobile transceivers** (Such as those used in police cars, fire trucks, ambulances and taxis.) These usually have the antenna mounted on the outside of the vehicle.

3) **Long-range transmitters and transceivers such as commercial broadcast transmitters** (Radio and TV broadcast antenna towers) and amateur (HAM) radios.

**NOTE:** Other types of hand held devices, such as cordless phones, laptop computers, AM/FM radios, TV sets, CD players, cassette players and small appliances such as electric shavers and hair dryers, as far as we know, are not likely to cause EMI problems to your powered vehicle.

## **Powered Vehicle Electromagnetic Interference (EMI)**

Because EM energy rapidly becomes more intense as one moves closer to the transmitting antenna, the EM field from hand-held radio wave sources (transceivers) are of special concern. It is possible to unintentionally bring high levels of EM energy close to the powered vehicle's control system while using these devices. This can affect powered vehicle movement and braking. Therefore, the warnings listed below are recommended to prevent possible interference with the control system of the powered vehicle.

### **WARNINGS**

Electromagnetic interference (EMI) from sources such as radio and TV stations, amateur radio (HAM) transmitters, two-way radios and cellular phones can affect powered vehicles.

Following the warnings listed below should reduce the chance of unintended brake release or powered vehicle **movement which could result in serious injury**:

- 1) Do not operate hand-held transceivers (transmitters-receivers) such as citizen band (CB) radios, or turn ON personal communication devices such as cellular phones, while the powered vehicle is ON;
- 2) Be aware of nearby transmitters, such as radio or TV stations and try to avoid coming close to them
- 3) On appearance of unintended movements or brake release occurrences, switch the powered vehicle OFF **as soon as it is safe**.
- 4) Be aware that adding accessories or components, or modifying the powered vehicle, may make it more susceptible to EMI (Note: there is no easy way to evaluate their effect on the overall immunity level of the powered vehicle).
- 5) Please report to us all incidents of unintended movement or brake release and note whether there is a source of EMI nearby.

### **Important information**

- 1) 10 volts per meter (V/m) is a generally achievable and useful immunity level against EMI (as of May 1994). The higher the level the greater the protection;
- 2) This product as delivered to you has an immunity level of 20 V/m.





---

Kibbutz Afikim, 15148, Israel  
mainbox@afiscooters.com  
**www.afiscooters.com**